

JC502 VESA Mount

User Manual



SAFETY INSTRUCTIONS



WARNING: Before beginning, turn off the media player, disconnect the AC adapter from the electrical outlet and the media player, and remove any other external cables from the media player.



Note: The VESA Mount is compatible with the following Model: Giada VM27

VESA MOUNTING MATERIALS



Main Bracket




Step Screws



M4 Screws


Parts	Quantity
Main Bracket	1
Step Screws ($\Phi 4.4 \times 3 + \Phi 8 \times 1.5$)	3
M4 Screws	4

DIMENSIONS



INSTALLATION

1. Assemble the Main Bracket (in the direction shown in the following figure) to the rear of a compatible display with the four M4 Screws.



2. Fix Step Screws on the media player as shown below



3. Mount the player

